

NCES

ELEMENTS OF CHEMICAL REACTION ENGINEERING

edition

H. SCOTT FOGLER

*Ame and Catherine Vennema Professor
of Chemical Engineering
The University of Michigan, Ann Arbor*

ring

PRENTICE-HALL, Englewood Cliffs, New Jersey 07632

Library of Congress Cataloging-in-Publication Data

FOGLER, H. SCOTT.

Elements of chemical reaction engineering.

(Prentice-Hall international series in the physical
and chemical engineering sciences)

Includes bibliographies and index.

1. Chemical reactors. I. Title. II. Series.

TP157.F65 1986 660.2'81 85-28270

ISBN 0-13-263476-7

Manufacturing buyer: *Gordon Osbourne*

© 1986 by Prentice-Hall, Inc.

A Division of Simon & Schuster

Englewood Cliffs, New Jersey 07632

All rights reserved. No part of this book may be
reproduced, in any form or by any means,
without permission in writing from the publisher.

Printed in the United States of America

10 9 8 7 6 5 4 3 2

ISBN 0-13-263476-7 025

Prentice-Hall International (UK) Limited, *London*

Prentice-Hall of Australia Pty. Limited, *Sydney*

Prentice-Hall Canada Inc., *Toronto*

Prentice-Hall Hispanoamericana, S.A., *Mexico*

Prentice-Hall of India Private Limited, *New Delhi*

Prentice-Hall of Japan, Inc., *Tokyo*

Prentice-Hall of Southeast Asia Pte. Ltd., *Singapore*

Editora Prentice-Hall do Brasil, Ltda., *Rio de Janeiro*

Whitehall Books Limited, *Wellington, New Zealand*

Contents

PREFACE	xvii
CHAPTER 1: MOLE BALANCES	1
1.1 DEFINITION OF THE RATE OF REACTION, $-r_A$	2
1.2 THE GENERAL MOLE BALANCE EQUATION	6
1.3 BATCH REACTORS	8
1.4 CONTINUOUS-FLOW REACTORS	10
1.4.1 Continuous-Stirred Tank Reactor	10
1.4.2 Tubular Reactor	11
1.5 INDUSTRIAL REACTORS	15
SUMMARY	19
QUESTIONS AND PROBLEMS	20
SOME THOUGHTS ON PROBLEM SOLVING	23
SUPPLEMENTARY READING	27
CHAPTER 2: CONVERSION AND REACTOR SIZING	28
2.1 DEFINITION OF CONVERSION	28
2.2 DESIGN EQUATIONS	29
2.2.1 Batch Systems	29
2.2.2 Flow Systems	31

2.3	APPLICATIONS OF THE DESIGN EQUATIONS	33
2.4	REACTORS IN SERIES	37
2.5	SOME FURTHER DEFINITIONS	47
	SUMMARY	49
	QUESTIONS AND PROBLEMS	51
	SOME THOUGHTS ON PROBLEM SOLVING	56
	SUPPLEMENTARY READING	57
CHAPTER 3: RATE LAWS AND STOICHIOMETRY		59
3.1	BASIC DEFINITIONS	59
3.1.1	The Reaction Rate Constant	60
3.1.2	The Reaction Order	63
3.1.3	Elementary Reactions and Molecularity	65
3.1.4	Reversible Reactions	67
3.1.5	Nonelementary Reactions	68
3.2	PRESENT STATUS OF OUR APPROACH TO REACTOR SIZING AND DESIGN	69
3.3	STOICHIOMETRIC TABLE	70
3.3.1	Batch Systems	71
3.3.2	Constant-Volume Reaction Systems	73
3.3.3	Flow Systems	76
3.3.4	Volume Change with Reaction	77
3.4	REACTIONS WITH PHASE CHANGE	86
	SUMMARY	89
	QUESTIONS AND PROBLEMS	92
	SOME THOUGHTS ON PROBLEM SOLVING	99
	SUPPLEMENTARY READING	103
CHAPTER 4: ISOTHERMAL REACTOR DESIGN		105
4.1	DESIGN STRUCTURE FOR ISOTHERMAL REACTORS	106
4.2	SCALE-UP OF LIQUID-PHASE BATCH REACTOR DATA TO THE DESIGN OF A CSTR	106
4.2.1	Batch Operation	108
4.2.2	Design of CSTRs	112
4.3	TUBULAR FLOW REACTORS	121
4.4	PRESSURE DROP IN REACTORS	126
4.4.1	Flow through a Packed Bed	126
4.4.2	Pressure Drop and the Rate Law	130
4.4.3	Pressure Drop in Pipes	135

Contents	Contents	ix
33	4.5 REVERSIBLE REACTIONS	136
37	4.5.1 Role of Nitric Oxide in Smog Formation	138
47	4.6 UNSTEADY-STATE OPERATION OF REACTORS	142
49	4.6.1 Startup of a CSTR	143
51	4.6.2 Semibatch Reactors	144
56	4.6.3 Reactive Distillation	152
57	4.7 RECYCLE REACTORS	154
	SUMMARY	158
59	QUESTIONS AND PROBLEMS	159
59	SOME THOUGHTS ON PROBLEM SOLVING	175
60	SUPPLEMENTARY READING	178
63	CHAPTER 5: COLLECTION AND ANALYSIS OF RATE DATA	179
65	5.1 BATCH REACTOR DATA	180
67	5.1.1 Differential Method of Rate Analysis	180
68	5.1.2 Gas-Phase Reactions with Total Pressure as the Measured Variable	182
	5.1.3 Integral Method	189
69	5.2 METHOD OF INITIAL RATES	195
70	5.3 METHOD OF HALF-LIVES	197
71	5.4 LEAST-SQUARES ANALYSIS	199
73	5.4.1 Linearization of the Rate Law	199
76	5.4.2 Nonlinear Analysis	200
77	5.4.3 Weighted Least-Squares Analysis	201
86	5.5 DIFFERENTIAL REACTORS	203
89	5.6 EVALUATION OF LABORATORY REACTORS	206
92	5.6.1 Integral (Fixed-bed) Reactor	206
99	5.6.2 Stirred Batch Reactor	207
103	5.6.3 Stirred Contained Solids Reactor (SCSR)	208
	5.6.4 Continuous-Stirred Tank Reactor (CSTR)	208
105	5.6.5 Straight-through Transport Reactor	209
106	5.6.6 Recirculating Transport Reactor	210
	5.6.7 Summary of Reactor Ratings	211
106	5.7 EXPERIMENTAL DESIGN	211
108	5.7.1 Finding the Rate Law	211
112	5.7.2 Experimental Planning	213
121	SUMMARY	216
126	QUESTIONS AND PROBLEMS	218
126	SOME THOUGHTS ON PROBLEM SOLVING	225
130	SUPPLEMENTARY READING	229
135		

CHAPTER 6: CATALYSIS AND CATALYTIC REACTORS	231
6.1 CATALYSTS	231
6.1.1 Definitions	231
6.1.2 Catalyst Properties	233
6.2 STEPS IN A CATALYTIC REACTION	235
6.2.1 Adsorption Isotherms	238
6.2.2 Surface Reaction	244
6.2.3 Desorption	245
6.2.4 The Rate-Limiting Step	245
6.3 SYNTHESIZING A RATE LAW, MECHANISM, AND RATE-LIMITING STEP	246
6.3.1 Is the Adsorption of Cumene Rate Limiting?	249
6.3.2 Is the Surface Reaction Rate Limiting?	253
6.3.3 Is the Desorption of Benzene Rate Limiting?	254
6.3.4 Summary of the Cumene Decomposition	255
6.4 DESIGN OF REACTORS FOR GAS-SOLID REACTIONS	258
6.4.1 Basic Guidelines	258
6.4.2 The Design Equation	258
6.5 HETEROGENEOUS DATA ANALYSIS FOR REACTOR DESIGN	261
6.5.1 Deducing a Rate Law from the Experimental Data	262
6.5.2 Finding a Mechanism Consistent with Experimental Observations	264
6.5.3 Evaluation of the Rate-Law Parameters	265
6.5.4 Reactor Design	268
6.6 CATALYST DEACTIVATION	273
6.6.1 Deactivation by Sintering or Aging	274
6.6.2 Deactivation by Coking or Fouling	276
6.6.3 Deactivation by Poisoning	276
6.6.4 Temperature-Time Trajectories	280
6.6.5 Effect of Deactivation on Selectivity	282
6.6.6 Determining the Order of Deactivation	284
6.7 MOVING-BED REACTORS	288
SUMMARY	294
QUESTIONS AND PROBLEMS	296
SOME THOUGHTS ON PROBLEM SOLVING	310
SUPPLEMENTARY READING	314
CHAPTER 7: NONELEMENTARY HOMOGENEOUS REACTIONS	316
7.1 FUNDAMENTALS	317
7.1.1 Active Intermediates	317
7.1.2 Pseudo-Steady-State Hypothesis (PSSH)	319

231
231
231
233
235
238
244
245
245
246
249
253
254
255
258
258
258
261
262

264
265
268
273
274
276
276
280
282
284
288
294
296
310
314

316
317
317
319

7.2	SEARCHING FOR A MECHANISM	320
7.2.1	General Considerations	321
7.2.2	Hydrogen Bromide Reaction	324
7.3	ENZYMATIC REACTION FUNDAMENTALS	328
7.3.1	Definitions and Mechanisms	328
7.3.2	Michaelis-Menten Equation	331
7.3.3	Batch Reactor Calculations	334
	SUMMARY	336
	QUESTIONS AND PROBLEMS	337
	SOME THOUGHTS ON PROBLEM SOLVING	345
	SUPPLEMENTARY READING	348
	 CHAPTER 8: NONISOTHERMAL REACTOR DESIGN	 349
8.1	RATIONALE	349
8.2	THE ENERGY BALANCE	351
8.2.1	First Law of Thermodynamics	351
8.2.2	Evaluating the Work Term	352
8.2.3	Dissecting the Molar Flow Rates to Obtain the Heat of Reaction	353
8.2.4	Dissecting the Enthalpies	355
8.2.5	Relating $\Delta H_R(T)$, $\Delta H_R(T_R)$, and ΔC_p	356
8.2.6	Constant or Mean Heat Capacities	358
8.2.7	Variable Heat Capacities	358
8.2.8	Heat Added to the Reactor, \dot{Q}	361
8.3	NONISOTHERMAL CONTINUOUS-FLOW REACTORS AT STEADY STATE	362
8.3.1	Application to the CSTR	363
8.3.2	Adiabatic Tubular Flow Reactor	372
8.3.3	Steady-State Tubular Flow Reactor with Heat Exchange	379
8.4	EQUILIBRIUM CONVERSION	383
8.4.1	Adiabatic Temperature and Equilibrium Conversion	384
8.4.2	Optimum Feed Temperature	387
8.5	UNSTEADY-STATE OPERATION	388
8.5.1	The General Equation	389
8.5.2	Unsteady Operation of Plug-Flow Reactors	390
8.5.3	Unsteady CSTR Operation	392
8.5.4	Batch Reactors	393

8.6	NONADIABATIC REACTOR OPERATION: OXIDATION OF SULFUR DIOXIDE EXAMPLE	397
8.6.1	Manufacture of Sulfuric Acid	397
8.6.2	Catalyst Quantities	401
8.6.3	Reactor Configuration	401
8.6.4	Operating Conditions	402
8.7	MULTIPLE STEADY STATES	412
8.7.1	Heat-Removed Term, $R(T)$	413
8.7.2	Heat of Generation, $G(T)$	413
8.7.3	Ignition-Extinction Curve	415
8.7.4	Steady-State Bifurcation Analysis	419
	SUMMARY	425
	QUESTIONS AND PROBLEMS	426
	SOME THOUGHTS ON PROBLEM SOLVING	445
	SUPPLEMENTARY READING	450
	CHAPTER 9: MULTIPLE REACTIONS	452
9.1	CONDITIONS FOR MAXIMIZING THE DESIRED PRODUCT IN PARALLEL REACTIONS	454
9.1.1	Maximizing S for One Reactant	455
9.1.2	Maximizing S for Two Reactants	457
9.2	MAXIMIZING THE DESIRED PRODUCT IN SERIES REACTIONS	461
9.3	STOICHIOMETRIC TABLE FOR MULTIPLE REACTIONS	465
9.4	HYDRODEALKYLATION OF MESITYLENE	471
9.4.1	Description of the Reacting System	471
9.4.2	Optimization of Xylene Production in a Packed-Bed Reactor	475
9.5	NONISOTHERMAL CHEMICAL REACTIONS	479
9.6	WHAT IF THE PROCEDURE IN TABLE 9-2 CAN'T BE APPLIED?	481
	SUMMARY	491
	QUESTIONS AND PROBLEMS	494
	SUPPLEMENTARY READING	508
	CHAPTER 10: EXTERNAL DIFFUSION EFFECTS IN HETEROGENEOUS REACTIONS	509
10.1	MASS-TRANSFER FUNDAMENTALS	510
10.1.1	Definitions	510
10.1.2	Molar Flux	511
10.1.3	Fick's First Law	513

397	10.2	BINARY DIFFUSION	514
397	10.2.1	Evaluating the Molar Flux	517
401	10.2.2	Boundary Conditions	517
401	10.2.3	Modeling Diffusion without Reaction	523
402	10.2.4	Temperature and Pressure Dependence of D_{AB}	523
412	10.2.5	Modeling Diffusion with Chemical Reaction	523
413	10.3	EXTERNAL RESISTANCE TO MASS TRANSFER	524
413	10.3.1	Mass-Transfer Coefficient	525
415	10.3.2	Mass Transfer to a Single Particle	528
419	10.3.3	Mass-Transfer-Limited Reactions in Packed Beds	532
425	10.3.4	Mass-Transfer-Limited Reaction on Surfaces of Metals	539
426	10.4	WHAT IF . . . ? (PARAMETER SENSITIVITY)	544
445		SUMMARY	549
450		QUESTIONS AND PROBLEMS	550
		SOME THOUGHTS ON PROBLEM SOLVING	558
452		SUPPLEMENTARY READING	559
454	CHAPTER 11:	DIFFUSION AND REACTION	
455		IN POROUS CATALYSTS	560
457	11.1	DIFFUSION AND REACTION IN SPHERICAL CATALYST PELLETS	561
461	11.1.1	Effective Diffusivity	561
465	11.1.2	Derivation of the Differential Equation	
471		Describing Diffusion and Reaction	562
471	11.1.3	Writing the Equation in Dimensionless Form	565
475	11.1.4	Solution to the Differential Equation	
479		for a First-Order Reaction	567
481	11.2	INTERNAL EFFECTIVENESS FACTOR	569
491	11.3	FALSIFIED KINETICS	572
494	11.4	OVERALL EFFECTIVENESS FACTOR	574
508	11.5	ESTIMATION OF DIFFUSION- AND REACTION-LIMITED REGIMES	577
	11.5.1	Wiesz-Prater Criterion for Internal Diffusion	577
	11.5.2	Mears' Criterion for External Diffusion	579
509	11.6	MASS TRANSFER AND REACTION IN A PACKED BED	580
510	11.7	DETERMINATION OF LIMITING SITUATIONS FROM REACTION DATA	586
510		SUMMARY	587
511		QUESTIONS AND PROBLEMS	588
513		SUPPLEMENTARY READING	595

CHAPTER 12: MULTIPHASE REACTORS	596
12.1 SLURRY REACTORS	597
12.1.1 Rate of Gas Absorption	599
12.1.2 Transport to Catalyst	599
12.1.3 Diffusion and Reaction in the Catalyst Pellet	600
12.1.4 The Rate Law	600
12.1.5 Determining the Limiting Step	600
12.1.6 Slurry Reactor Design	609
12.2 TRICKLE BED REACTORS	610
12.2.1 Fundamentals	611
12.2.2 Limiting Situations	614
12.2.3 Evaluating the Transport Coefficients	614
SUMMARY	622
QUESTIONS AND PROBLEMS	622
SUPPLEMENTARY READING	627
CHAPTER 13: DISTRIBUTIONS OF RESIDENCE TIMES FOR CHEMICAL REACTORS By L. F. Brown and H. S. Fogler	629
13.1 GENERAL CHARACTERISTICS	629
13.1.1 Residence-Time Distribution Function	632
13.2 MEASUREMENT OF THE RESIDENCE-TIME DISTRIBUTION	633
13.2.1 Pulse Input	633
13.2.2 Positive-Step Tracer Experiment	638
13.2.3 Negative-Step Tracer Experiment	639
13.3 CHARACTERISTICS OF THE RTD	640
13.3.1 Integral Relationships	640
13.3.2 Mean Residence Time	642
13.3.3 Other Moments of the RTD	644
13.3.5 Normalized RTD Function $E(\theta)$	647
13.3.5 Internal-Age Distribution $I(t)$	647
13.3.6 RTDs and Chemical Reaction Rates	650
13.4 THE RTD IN IDEAL REACTORS	651
13.4.1 RTDs in Batch and Plug-Flow Reactors	651
13.4.2 Single CSTR RTD	651
13.4.3 The RTD in CSTRs in Series	653
13.4.4 Plug Flow-CSTR Series RTD	656
13.4.5 Laminar Flow Reactor	659

596	13.5	RTDs IN REAL REACTOR SYSTEMS	661
597	13.5.1	Tubular Reactor RTDs	661
599	13.5.2	RTDs in a Continuous-Stirred Tank	665
599	13.5.3	Tests on Some Fluidized Beds	666
600	13.6	REACTOR MODELING WITH THE RTD	668
600	13.7	MICROMIXING: THE SEGREGATION MODEL	669
600	13.7.1	Segregation Model	669
609	13.7.2	Analysis of Reactors with Completely Segregated Mixing	670
610		SUMMARY	673
611		QUESTIONS AND PROBLEMS	674
614		SUPPLEMENTARY READING	679
622			
622			
627			
	CHAPTER 14:	ANALYSIS OF NONIDEAL REACTORS	680
		By H. S. Fogler and L. F. Brown	
629	14.1	THE BASIC IDEA	680
	14.1.1	Mathematical Tractability	681
	14.1.2	Physical Realism	681
629	14.1.3	The Model Must Have at Most Two Parameters	681
632	14.2	MODELING REAL REACTORS WITH COMBINATIONS OF IDEAL REACTORS	682
633	14.2.1	Real CSTR Modeled with an Exchange Volume	682
633	14.2.2	Real CSTR Modeled Using Bypassing and Dead Space	685
638	14.3	TESTING A MODEL AND DETERMINING ITS PARAMETERS	686
639	14.3.1	Two CSTRs with Interchange	687
640	14.3.2	Tracer Use to Determine Parameters in CSTR-with-Deadspace-and-Bypass Model	692
640	14.4	MODELS OF TANK REACTORS	696
642	14.5	MODELS OF TUBULAR REACTORS	697
644	14.5.1	Nonideality in Tubular Reactors	697
647	14.5.2	Dispersion Model	697
650	14.6	MAXIMUM MIXEDNESS	707
651	14.7	USING THE RTD VERSUS THE NEED FOR A MODEL	712
651		SUMMARY	712
653		QUESTIONS AND PROBLEMS	714
656		SUPPLEMENTARY READING	719
659			

APPENDICES

A	GRAPHICAL AND NUMERICAL TECHNIQUES	722
A.1	Integration: The Graphical Form of Simpson's Rule	722
A.2	Useful Integrals in Reactor Design	724
A.3	Equal-Area Graphical Differentiation	726
A.4	Solutions to Differential Equations	729
A.5	Numerical Evaluation of Integrals	730
A.6	Solutions to a First-Order Differential Equation	732
B	IDEAL GAS CONSTANT AND CONVERSION FACTORS	734
C	THERMODYNAMIC RELATIONSHIPS INVOLVING THE EQUILIBRIUM CONSTANT	736
D	PREDICTION OF BINARY GAS PHASE DIFFUSIVITIES	738
E	MEASUREMENT OF SLOPES	740
F	GUIDED DESIGNS	743
F.1	Comprehensive Problem	743
F.2	Continuous Food Processing Plant	746
F.3	Plant Safety	747
F.4	Original Final Exam Problems	748
	INDEX	761

1.4 Continuous-Flow Reactors

1.4.1 Continuous-stirred tank reactor

A type of reactor used very commonly in industrial processing is a stirred tank operated continuously (see Figure 1-4). It is referred to as the *continuous-stirred tank reactor* (CSTR) or *backmix reactor*. The CSTR is normally run at steady state, and is usually operated so as to be quite well mixed. As a result of the latter quality, the CSTR is generally modeled as having no spatial variations in concentration, temperature, or reaction rate throughout the vessel. Since the temperature and concentration are identical everywhere within the reaction vessel, they are the same at the exit point as they are elsewhere in the tank. Thus the temperature and concentration in the exit stream are modeled as being the same as those inside the reactor. In systems where mixing is highly nonideal, the well-mixed model is inadequate and we must resort to other modeling techniques, such as residence-time distributions, in order to obtain meaningful results. This topic is discussed in Chapters 13 and 14.




Figure 1-4 Continuous-stirred tank reactor.

When the general mole balance equation

$$F_{j0} - F_j + \int_V r_j dV = \frac{dN_j}{dt} \quad (1-4)$$


is applied to a CSTR operated at steady state (i.e., conditions do not change with time),

$$\frac{dN_j}{dt} = 0$$

in which there are no spatial variations in the rate of reaction, i.e.,

$$\int_V r_j dV = V r_j$$

it takes the familiar form known as the *design equation* for a CSTR:



$$V = \frac{F_{j0} - F_j}{-r_j} \quad (1-6)$$

ing is a stirred
the *continuous*-
normally run at
s a result of the
ul variations in
essel. Since the
reaction vessel,
ank. Thus the
ng the same as
ideal, the well-
techniques, such
ts. This topic is

The CSTR design equation gives the reactor volume necessary to reduce the entering flow rate of species, j , F_{j0} , to the exit flow rate F_j . We note that the CSTR is modeled such that the conditions in the exit stream (e.g., concentration, temperature) are identical to those in the tank. The molar flow rate F_j is just the product of the concentration of species j and the volumetric flow rate v :

$$F_j = C_j \cdot v \quad (1-7)$$

$$\frac{\text{moles}}{\text{time}} = \frac{\text{moles}}{\text{volume}} \cdot \frac{\text{volume}}{\text{time}}$$

1.4.2 Tubular reactor

In addition to the batch and backmix (CSTR) reactors, another type of reactor commonly used in industry is the *tubular reactor*. It consists of a cylindrical pipe and is normally operated at steady state, as is the CSTR. For the purposes of the material presented here, we consider systems in which the flow is highly turbulent and the flow field may be modeled by that of plug flow. That is, there is no radial variation in concentration. (The laminar flow reactor is discussed in Chapter 13.)

In the tubular reactor, the reactants are continually consumed as they flow down the length of the reactor. In modeling the tubular reactor, we assume that the concentration varies continuously in the axial direction through the reactor. Consequently, the reaction rate, which is a function of concentration for all but zero-order reactions, will also vary axially. To develop the design equation, we shall divide (conceptually) the reactor into a number of subvolumes so that within each subvolume ΔV , the reaction rate may be considered spatially uniform (see Figure 1-5). We now focus our attention on the subvolume that is located a distance y from the entrance of the reactor. Letting $F_j(y)$ represent the molar flow rate of j into volume ΔV at y and $F_j(y + \Delta y)$ the molar flow of j out of the volume at the point $(y + \Delta y)$, the general mole balance on species j is

$$F_{j0} - F_j + \int_0^V r_j dV = \frac{dN_j}{dt} \quad (1-4)$$

(1-4)

t change with

2.,




Figure 1-5 Tubular reactor.

In spatially uniform subvolume ΔV ,

$$\int^{\Delta V} r_j dV = r_j \Delta V$$

For a tubular reactor operated at steady state,

$$\frac{dN_j}{dt} = 0$$

equation (1-4) becomes

$$F_j(y) - F_j(y + \Delta y) + r_j \Delta V = 0 \quad (1-8)$$

In this expression r_j is an indirect function of y . That is, r_j is a function of reactant concentration, which is a function of the position y down the reactor. The volume ΔV is the product of the cross-sectional area A of the reactor and the reactor length Δy .

$$\Delta V = A \Delta y$$

We now substitute in equation (1-8) for ΔV and then divide by Δy to obtain

$$-\left[\frac{F_j(y + \Delta y) - F_j(y)}{\Delta y} \right] = -Ar_j$$

The term in brackets resembles the definition of the derivative

$$\lim_{\Delta x \rightarrow 0} \left[\frac{f(x + \Delta x) - f(x)}{\Delta x} \right] = \frac{df}{dx}$$

Taking the limit as Δy goes to zero, we obtain

$$-\frac{dF_j}{dy} = -Ar_j$$

or dividing by -1 , we have

$$\frac{dF_j}{dy} = Ar_j \quad (1-9)$$

It is usually most convenient to have the reactor volume V rather than the reactor length y as the independent variable. Accordingly, we shall change variables using the relation $dV = A dy$ to obtain one form of the design equation for a tubular reactor:

$$\frac{dF_j}{dV} = r_j \quad (1-10)$$

We also note that for a reactor in which the cross-sectional area A varies along the length of the reactor, the design equation remains unchanged. This equation can be generalized for the reactor shown in Figure 1-6, in a manner similar to that presented above, by utilizing the volume coordinate V rather than a linear coordinate y . After passing through volume V , species j enters subvolume ΔV at V at a molar flow rate $F_j(V)$. Species j leaves subvolume ΔV at volume $(V + \Delta V)$ at a molar flow rate $F_j(V + \Delta V)$. As before, ΔV is chosen small enough so that there is no spatial variation of reaction rate within the subvolume:

$$G = \int^{\Delta V} r_j dV = r_j \Delta V \quad (1-11)$$




Figure 1-6


After accounting for steady-state operation in equation (1-4), it is combined with equation (1-11) to yield

$$F_j(V) - F_j(V + \Delta V) + r_j \Delta V = 0$$

Rearranging gives us

$$\frac{F_j(V + \Delta V) - F_j(V)}{\Delta V} = r_j$$

and taking the limit as $\Delta V \rightarrow 0$, we again obtain equation (1-10):



$$\frac{dF_j}{dV} = r_j$$

(1-10)

Consequently, we see that equation (1-10) applies equally well to our model of tubular reactors of variable and constant cross-sectional area, although it is doubtful that one would find a reactor of the shape shown in Figure 1-6. The conclusion drawn from the application of the design equation is an important one: that the extent of reaction achieved in a plug-flow tubular reactor does not depend on its shape, only on its total volume.

To obtain some insight into things to come, consider the following example of how one can use the tubular reactor design equation (1-10).

Example 1-3 How Large Is It?

The first-order reaction



is carried out in a tubular reactor in which the volumetric flow rate is constant. Derive an equation relating the reactor volume to the entering and exiting concentrations of A, the rate constant k , and the volumetric flow rate v . Determine the reactor volume necessary to reduce the exiting concentration to 10% of the entering concentration when the volumetric flow rate is $10 \text{ dm}^3/\text{min}$ (i.e., liters/min) and the specific reaction rate, k , is 0.23 per minute.

Solution

For a tubular reactor, the mole balance on species A ($j = A$) was shown to be

$$\frac{dF_A}{dV} = r_A \quad (1-10)$$

For a first-order reaction, the rate law (which is discussed in Chapter 3) is

$$-r_A = kC_A \quad (\text{E1-3.1})$$

Since the volumetric flow rate, v_0 , is constant,

$$\frac{dF_A}{dV} = \frac{d(C_A v_0)}{dV} = v_0 \frac{dC_A}{dV} = r_A \quad (\text{E1-3.2})$$

Substituting for r_A in equation (E1-3.1) yields

$$-\frac{v_0}{dV} dC_A = -r_A = kC_A \quad (\text{E1-3.3})$$

Rearranging gives us

$$-\frac{v_0}{k} \left(\frac{dC_A}{C_A} \right) = dV$$

Using the conditions at the entrance of the reactor that when $V = 0$, then $C_A = C_{A0}$,

$$-\frac{v_0}{k} \int_{C_{A0}}^{C_A} \frac{dC_A}{C_A} = \int_0^V dV \quad (\text{E1-3.4})$$

Reactor sizing

vell to our model
a, although it is
ore 1-6. The con-
portant one: that
not depend on its
ollowing example

te is constant.
d exiting con-
v. Determine
to 10% of the
m³/min (i.e.,

s shown to be

$$(1-10)$$

napter 3) is

$$(E1-3.1)$$

$$(E1-3.2)$$

$$(E1-3.3)$$

$V = 0$, then

$$(E1-3.4)$$

When is a batch
reactor used?

What are the
advantages and
disadvantages of a
CSTR?

This gives

$$V = \frac{v_0}{k} \ln \frac{C_{A0}}{C_A} \quad (E1-3.5)$$

Substituting C_{A0} , C_A , v_0 , and k in equation (E1-3.5), we have

$$V = \frac{10 \text{ dm}^3/\text{min}}{0.23 \text{ min}^{-1}} \ln \frac{C_{A0}}{0.1 C_{A0}} = \frac{10}{0.23} \ln 10 = 100 \text{ dm}^3 \text{ (100 liters; } 0.1 \text{ m}^3\text{)}$$

We see that a reactor volume of 0.1 m^3 is necessary to convert 90% of species A entering into product B.

In the remainder of this chapter we look at slightly more detailed drawings of some typical industrial reactors and point out a few of the advantages and disadvantages of each.[†]

1.5 Industrial Reactors

A batch reactor is used for small-scale operation, for testing new processes that have not been fully developed, for the manufacture of expensive products, and for processes that are difficult to convert to continuous operations.

The reactor can be charged (i.e., filled) through the two holes shown at the top (Figure 1-7). The batch reactor has the advantage of high conversions that can be obtained by leaving the reactant in the reactor for long periods of time, but it also has the disadvantages of high labor costs per unit production, and large-scale production is difficult.

Although a semibatch reactor (Figure 1-8) has essentially the same disadvantages as the batch reactor, it has the advantages of good temperature control and the capability of minimizing unwanted side reactions through the maintenance of a low concentration of one of the reactants. The semibatch reactor is also used for two-phase reactions in which a gas is usually continuously bubbled through the liquid.

A continuous-stirred tank reactor (CSTR) is used when intense agitation is required. The CSTR can either be used by itself or, in the manner shown in Figure 1-9, as part of a series or battery of CSTRs. It is relatively easy to maintain good temperature control with a CSTR. There is, however, the disadvantage that the conversion of reactant per volume of reactor is the smallest of the flow reactors. Consequently, very large reactors are necessary to obtain high conversions.

The tubular reactor [i.e., plug-flow reactor (PFR)] is relatively easy to maintain (no moving parts), and it usually produces the highest conversion per reactor volume of any of the flow reactors. The disadvantage of the tubular reactor is that it is difficult to control temperature within the reactor, and hot spots can

[†]Chem. Eng. 63 (10), 211 (1956). See also *AIChE Modular Instruction Series E*, Vol. 6 (to appear in 1986).




Figure 1-7 Simple batch homogeneous reactor. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]




Figure 1-8 Semibatch reactor. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]




Figure 1-9 Battery of stirred tanks. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]

What are the
advantages and
disadvantages of a
PFR?

occur when the reaction is exothermic. The tubular reactor is commonly found either in the form of one long tube or as one of a number of shorter reactors arranged in a tube bank as shown in Figure 1-10. Most homogeneous liquid-phase




Figure 1-10 Longitudinal tubular reactor. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]

flow reactors are CSTRs, whereas most homogeneous gas-phase flow reactors are tubular.

A fixed-bed (packed-bed) reactor is essentially a tubular reactor, which is packed with solid catalyst particles (Figure 1-11). This heterogeneous reaction system is used most frequently to catalyze gas reactions. This reactor has the same difficulties with temperature control as other tubular reactors, and in addition, the catalyst is usually troublesome to replace. On occasion, channeling of the gas flow occurs, resulting in ineffective use of parts of the reactor bed. The advantage of the fixed-bed reactor is that for most reactions it gives the highest conversion per weight of catalyst of any catalytic reactor.




Figure 1-11 Longitudinal catalytic fixed-bed reactor. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]

Another type of catalytic reactor in common use is the fluidized-bed (Figure 1-12). The fluidized-bed reactor is analogous to the CSTR in that its contents, though heterogeneous, are well mixed, resulting in an even temperature distribution throughout the bed. The fluidized-bed reactor cannot be modeled as either a CSTR or a tubular reactor, but requires a model of its own. The temperature is relatively uniform throughout, thus avoiding hot spots. This type of reactor can handle large amounts of feed and solids, and has good temperature control; consequently, it is used in a large number of applications. The advantages of the ease of catalyst replacement or regeneration are sometimes offset by the high cost of the reactor and catalyst regeneration equipment.

se flow reactors are

r reactor, which is
neous reaction sys-
actor has the same
and in addition, the
ling of the gas flow
ne advantage of the
est conversion per




Figure 1-12 Fluidized-bed catalytic reactor. [Excerpted by special permission from *Chem. Eng.*, 63(10), 211 (Oct. 1956). Copyright (1956) by McGraw-Hill, Inc., New York, NY 10020.]

The aim of the preceding discussion on commercial reactors is to give a more detailed picture of each of the major types of industrial reactors: batch, semibatch, CSTR, tubular, fixed-bed (packed-bed), and fluidized-bed. Many variations and modifications of these commercial reactors are in current use; for further elaboration, we refer the reader to the detailed discussion of industrial reactors given by Walas.[†]

special per-
(1956) by

zed-bed (Figure
that its contents,
perature distribu-
e as either a
temperature is
e of reactor can
perature control;
vantages of the
the high cost of



SUMMARY

1. A **mole balance on species j** , which enters, leaves, reacts, and accumulates in a system volume V , is

$$F_{j0} - F_j + \int_V r_j dV = \frac{dN_j}{dt} \quad (\text{S1-1})$$

[†]S. M. Walas, *Reaction Kinetics for Chemical Engineers* (New York: McGraw-Hill, 1959), Chap. 11.

2. The kinetic rate law for r_j is solely a function of the properties of the reacting materials; it is an intensive quantity. The rate law is essentially an algebraic equation of concentration, not a differential equation. For homogeneous systems, typical units of $-r_A$ may be gram moles per second per liter, and for heterogeneous systems, typical units of $-r_A$ may be gram moles per second per gram of catalyst. By convention, $-r_A$ is the rate of disappearance of species A and r_A is the rate of formation of species A.
3. The differential mole balance for a tubular reactor operated at steady state is

$$\frac{dF_j}{dV} = r_j \quad (\text{S1-2})$$

4. The mole balance on a CSTR (backmix reactor) can be expressed by the equation

$$V = \frac{F_{j0} - F_j}{-r_j} \quad (\text{S1-3})$$

5. A mole balance on a batch reactor gives

$$\int_0^V r_j dV = \frac{dN_j}{dt} \quad (\text{S1-4})$$

6. When there are no spatial variations in conditions and material properties within the reactor, equation (S1-4) can be written

$$\frac{1}{V} \frac{dN_j}{dt} = r_j \quad (\text{S1-5})$$

QUESTIONS AND PROBLEMS

I wish I had an answer for that, because I'm getting tired of answering that question.

Yogi Berra, New York Yankees
Sports Illustrated, June 11, 1984

- P1-1 Make a list of the most important things that you learned in this chapter.
- P1-2 What assumptions were made in the derivation of the design equation for
- The batch reactor?
 - The CSTR?
 - The plug-flow reactor?
- P1-3 State in words the meanings of $-r'_A$ and r'_A .
- P1-4 Write the design equation for a backmix reactor that is not well mixed and consequently has a spatial variation in the reaction rate throughout the reactor volume.

Conversion 2 and Reactor Sizing


Be more concerned with your character than with your reputation, because character is what you really are while reputation is merely what others think you are.

John Wooden, coach, UCLA Bruins

The first chapter focused on the general mole balance equation; the balance was applied to the three most common types of industrial reactors, and a design equation was developed for each reactor type. In Chapter 2 we first define *conversion* and then rewrite the design equations in terms of conversion. After carrying out this operation, we show how one may size a reactor (i.e., determine the reactor volume necessary to achieve a specified conversion) once the relationship between reaction rate, r_A , and conversion is known.


2.1 Definition of Conversion

In defining conversion, we choose one of the reactants as the basis of calculation and then relate the other species involved in the reaction to this basis. In most instances it is best to choose the limiting reactant as the basis of calculation. We develop the stoichiometric relationships and design equations by considering the general reaction



The capital letters represent chemical species and the lowercase letters represent stoichiometric coefficients. Taking species A as our basis of calculation, we divide

the reaction expression through by the stoichiometric coefficient of species A, in order to arrange the reaction expression in the form



to put every quantity on a "per mole of A" basis.

A convenient way to relate the number of moles of each of the species in the reaction to one another is through the use of the quantity called **conversion**. The conversion X_A is the number of moles of A that have reacted per mole of A fed to the system:

$$\text{Definition of } X \quad X_A = \frac{\text{moles of A reacted}}{\text{moles of A fed}}$$

For the sake of brevity, we eliminate the subscript A and let $X \equiv X_A$. However, when considering multiple reactions (see Chapter 9) and certain other reaction schemes, it is often necessary to retain the subscript.

2.2 Design Equations

2.2.1 Batch systems

In most batch reactors, the longer the reactant is in the reactor, the more reactant is converted to product until either equilibrium is reached or the reactant is exhausted. Consequently, in batch systems the conversion X will be a function of the time the reactants spend in the reactor. If N_{A0} is the number of moles of A initially, then the total number of moles of A that have reacted after a time t is $N_{A0}X$:

$$\begin{aligned} \left[\begin{array}{c} \text{moles of A} \\ \text{consumed} \end{array} \right] &= \left[\begin{array}{c} \text{moles of A} \\ \text{fed} \end{array} \right] \cdot \left[\begin{array}{c} \text{moles of A reacted} \\ \text{mole of A fed} \end{array} \right] \\ \left[\begin{array}{c} \text{moles of A} \\ \text{reacted} \\ \text{(consumed)} \end{array} \right] &= [N_{A0}] \cdot [X] \end{aligned}$$

Now, the number of moles of A that remain in the reactor after a time t , N_A , can be expressed in terms of N_{A0} and X :

$$\begin{aligned} \left[\begin{array}{c} \text{moles of A} \\ \text{in reactor} \\ \text{at time } t \end{array} \right] &= \left[\begin{array}{c} \text{moles of A} \\ \text{initially fed} \\ \text{to reactor at} \\ t = 0 \end{array} \right] - \left[\begin{array}{c} \text{moles of A that} \\ \text{have been consumed} \\ \text{by chemical} \\ \text{reaction} \end{array} \right] \\ N_A &= [N_{A0}] - [N_{A0}X] \end{aligned} \quad (2-1)$$

The number of moles of A in the reactor after a conversion X has been


achieved is

$$N_A = N_{A0} - N_{A0}X = N_{A0}(1 - X) \quad (2-3)$$

When there are no spatial variations in temperature or concentration, the mole balance on species A for a batch system reduces to the following equation:

$$\frac{dN_A}{dt} = r_A V \quad (2-4)$$

This equation is valid whether or not the reactor volume is constant. In the general reaction



reactant A is disappearing; therefore, we multiply both sides of equation (2-4) by -1 to obtain the mole balance for the batch reactor in the form

$$-\frac{dN_A}{dt} = (-r_A)V \quad (2-5)$$

The rate of disappearance of A, $-r_A$, in this reaction might be given by a rate law similar to equation (1-2), such as $-r_A = k C_A C_B$.

For batch reactors we are interested in determining how long we should leave the reactants in the reactor in order to achieve a certain conversion X . To learn this, we transform the mole balance, equation (2-4), in terms of conversion by differentiating equation (2-3),

$$N_A = N_{A0} - N_{A0}X \quad (2-3)$$

with respect to time, while remembering that N_{A0} is the number of moles of A initially present and is therefore a constant with respect to time.

$$\frac{dN_A}{dt} = 0 - N_{A0} \frac{dX}{dt}$$

Combining with equation (2-4) yields

$$-N_{A0} \frac{dX}{dt} = r_A V$$

The differential forms of the design equations appear often in reactor analysis and are particularly useful in the interpretation of reaction rate data. **For a batch reactor, the design equation in differential form is**

Batch reactor

$$N_{A0} \frac{dX}{dt} = -r_A V \quad (2-6)$$

(2-3)

concentration, the
following equation:

(2-4)

ent. In the general

(2-2)

equation (2-4) by
m

(2-5)

ven by a rate law

long we should
conversion X . To
ms of conversion

(2-3)

er of moles of A
e.

n reactor analysis
data. For a batch

(2-6)

Constant-volume batch reactors are found very frequently in industry. In particular, the laboratory bomb reactor for gas-phase reactions is widely used for obtaining reaction rate information on a small scale. Liquid-phase reactions in which the volume change during reaction is insignificant are frequently carried out in batch reactors when small-scale production is desired or operating difficulties rule out the use of continuous systems. For a *constant-volume batch reactor*, equation (2-5) can be arranged into the form

$$-\frac{1}{V} \frac{dN_A}{dt} = -\frac{d(N_A/V)}{dt} = -\frac{dC_A}{dt} = -r_A \quad (2-7)$$

For batch-reactor systems in which the volume varies while the reaction is proceeding, the volume may usually be expressed either as a function of time alone or of conversion alone, for either adiabatic or isothermal reactors. Consequently, the variables of the differential equation (2-6) can be separated in one of the following ways:

$$V dt = N_{A0} \frac{dX}{-r_A}$$

or

$$dt = N_{A0} \frac{dX}{-r_A V}$$

These equations are integrated with the limits that the reaction begins at time zero (i.e., $t = 0$, $X = 0$). When the volume is varied by some external source in a specific manner such as a piston compressing the reacting gas according to the equation ($V = V_1 + V_2 \sin \omega t$), the equation relating time and conversion one would use is

$$\int_0^t V dt = N_{A0} \int_0^X \frac{dX}{-r_A} \quad (2-8)$$

However, for the more common batch reactors in which volume is not a predetermined function of time, the time t necessary to achieve a conversion X is

Design



equation

$$t = N_{A0} \int_0^{X(t)} \frac{dX}{-r_A V} \quad (2-9)$$

Equation (2-6) is the differential form of the design equation, and equations (2-8) and (2-9) are the integral forms for a batch reactor. The differential form is generally used in the interpretation of laboratory rate data.

2.2.2 Flow systems

Normally, the conversion increases with the time the reactants spend in the reactor. For continuous-flow systems, this time usually increases with increasing reactor volume; consequently, the conversion X is a function of the reactor volume

V . If F_{A0} is the molar flow rate of species A fed to a system operated at steady state, the molar rate at which species A is reacting within the entire system will be $F_{A0}X$. The molar feed rate of A to the system *minus* the rate of reaction of A within the system will *equal* the molar flow rate of A leaving the system F_A . The preceding sentence can be written in the form of a mathematical statement in the following manner:

$$[F_{A0}] \cdot [X] = \frac{\text{moles of A fed}}{\text{time}} \cdot \frac{\text{moles of A reacted}}{\text{moles of A fed}}$$

$$F_{A0} \cdot X = \frac{\text{moles of A reacted}}{\text{time}}$$

$$\left[\begin{array}{c} \text{molar flow rate} \\ \text{at which A is} \\ \text{fed to the system} \end{array} \right] - \left[\begin{array}{c} \text{molar rate at} \\ \text{which A is} \\ \text{consumed within} \\ \text{the system} \end{array} \right] = \left[\begin{array}{c} \text{molar flow rate} \\ \text{at which A leaves} \\ \text{the system} \end{array} \right]$$



$$F_{A0} - F_{A0}X = F_A$$

Rearranging gives us

$$F_A = F_{A0}(1 - X) \quad (2-10)$$

Using this relationship between molar flow rate and conversion, it is now possible to express the design equations in terms of conversion for the flow reactors examined in Chapter 1.

CSTR or Backmix Reactor The equation resulting from a mole (mass) balance on species A for the reaction



occurring in a CSTR was given by equation (1-6), which can be rearranged to

$$F_{A0} - F_A = -r_A V \quad (2-11)$$

We now substitute for the exiting molar flow rate of A, F_A , in terms of the conversion X and the entering molar flow rate, F_{A0} , by using equation (2-10) in the form

$$F_{A0} - F_A = F_{A0}X$$

and combining it with equation (2-11) to give

$$F_{A0}X = -r_A V \quad (2-12)$$

We can rearrange equation (2-12) to determine the CSTR volume necessary to achieve a specified conversion X .

at steady state,
n will be $F_{A0}X$.
of A within the
The preceding
n the following



$$V = \frac{F_{A0}X}{(-r_A)_{\text{exit}}} \quad (2-13)$$

Since the exit composition from the reactor is identical to the composition inside the reactor, the rate of reaction is evaluated at the exit conditions.

Tubular Flow Reactor After multiplying both sides of the tubular reactor design equation (1-10) by -1 , we express the mole balance equation for species A in the reaction given by equation (2-2) as

$$\frac{-dF_A}{dV} = -r_A \quad (2-14)$$

For a flow system, F_A has previously been given in terms of the entering molar flow rate F_{A0} and the conversion X :

$$F_A = F_{A0} - F_{A0}X \quad (2-10)$$

Combining equations (2-10) and (2-14), the result is the differential form of the design equation of a plug-flow reactor:

$$F_{A0} \frac{dX}{dV} = -r_A \quad (2-15)$$

We now separate the variables and integrate with the limit $V = 0$ when $X = 0$ to obtain the plug-flow reactor volume necessary to achieve a specified conversion X :

$$V = F_{A0} \int_0^X \frac{dX}{-r_A} \quad (2-16)$$

To carry out the integrations in the batch and plug-flow reactor design equations (2-9) and (2-16), as well as evaluation of the CSTR design equation (2-13), we need to know how the reaction rate $-r_A$ varies with the concentration (hence conversion) of the reacting species. This relationship between reaction rate and concentration is developed in Chapter 3.

2.3 Applications of the Design Equations

The rate of disappearance of A, $-r_A$, is almost always a function of the concentrations of the various species present. When a single reaction is occurring, each of the concentrations can be expressed as a function of the conversion X ; consequently, $-r_A$ can be expressed as a function of X .

rate
leaves
em

(2-10)

sion, it is now
e flow reactors

(mass) balance

(2-2)

rearranged to

(2-11)

n terms of the
on (2-10) in the

(2-12)

ume necessary

A particularly simple functional dependence, yet one that does occur on many occasions, is $-r_A = kC_{A0}(1 - X)$. For this dependence, a plot of the reciprocal rate of reaction ($-1/r_A$) as a function of conversion yields a curve similar to the one shown in Figure 2-1, where

$$\frac{1}{-r_A} = \frac{1}{kC_{A0}} \cdot \frac{1}{1 - X}$$




Figure 2-1

If a reaction is carried out isothermally, the rate is usually greatest when the concentration of reactant is greatest, i.e., when there is negligible conversion ($X \cong 0$). (Hence $1/-r_A$ will be small.) When the reactant concentration is small (i.e., when conversion is large), the reaction rate will be small. (Consequently, $1/-r_A$ is large.) For irreversible reactions of greater than zero order,

$$-\frac{1}{r_A} \longrightarrow \infty \quad \text{as} \quad X \longrightarrow 1$$

These characteristics are illustrated by Figure 2-1 and the majority of reactions exhibit qualitatively similar curves.

Example 2-1 Sizing a CSTR

Shade the area in Figure 2-1 which, when multiplied by F_{A0} , would give the volume of a CSTR necessary to achieve 80% conversion (i.e., $X = 0.8$).

Solution

Equation (2-13) gives the volume of a CSTR as a function of F_{A0} , X , and $-r_A$; i.e.,

$$V = \frac{F_{A0}X}{-r_A} \quad (2-13)$$

does occur on
plot of the reci-
curve similar to

Algebraically,

$$V = F_{A0} \left(\frac{1}{-r_A} \right) X$$

$$\frac{V}{F_{A0}} = \left(\frac{1}{-r_A} \right) (0.8) \quad (\text{E2-1.1})$$

In a CSTR the composition, temperature, and conversion of the effluent stream are identical to that of the fluid within the reactor since perfect mixing is assumed. Therefore, we need to find the value of $-r_A$ (or reciprocal thereof) when $X = 0.8$.

From Figure E2-1.1 we see that when $X = 0.8$, $1/-r_A = 27.5$.

$$\frac{V}{F_{A0}} = (27.5)(0.8) = 22 \text{ dm}^3 \cdot \text{s/mol} \quad (\text{E2-1.2})$$

It's the rectangular
area for a CSTR




Figure E2-1.1


In Figure E2-1.1 this value of V/F_{A0} is equal to the area of a rectangle with a height $1/-r_A = 27.5$ and a base $X = 0.8$. This rectangle is shaded in the figure. If the entering molar flow rate, F_{A0} , was 20 mol/s, the CSTR reactor volume necessary to achieve 80% conversion would be

$$\begin{aligned} V &= 20 \frac{\text{mol}}{\text{s}} \cdot 22 \frac{\text{dm}^3 \cdot \text{s}}{\text{mol}} \\ &= 440 \text{ dm}^3 = 440 \text{ liters} \end{aligned}$$

would give the
 $X = 0.8$).

, X , and $-r_A$;

(2-13)



It's the area under
the curve for a
plug-flow reactor

The design equation for a plug-flow reactor (PFR) is

$$V = F_{A0} \int_0^X \frac{dX}{-r_A} \quad (2-16)$$

The integral in equation (2-16) can be evaluated from the area under the curve of a plot of $1/-r_A$ versus X (Figure 2-2). The product of this area and F_{A0} will give the tubular reactor volume necessary to achieve the specified conversion of A, X . For

2 E2-1.1




Figure 2-2

80% conversion the shaded area is roughly equal to $10 \text{ dm}^3 \cdot \text{s/g mol}$. The tubular reactor volume can be determined by multiplying this area (in $\text{dm}^3 \cdot \text{s/g mol}$) by F_{A0} (g mol/s). Shortcuts for evaluating the area under the curve in graphical integration are given in Appendix A.1.

Example 2-2 Comparing the CSTR and PFR Sizes

It is interesting to compare the volumes of a CSTR and a plug-flow reactor (PFR) required for the same job. To do this we shall use the data in Figure 2-1 to learn which reactor would require the smaller volume to achieve a conversion of 60%: a CSTR or a tubular reactor. The feed conditions are the same in both cases.

For the CSTR:

$$\frac{V}{F_{A0}} = \left(\frac{1}{-r_A} \right) X = (16)(0.6) = 9.6 \frac{\text{dm}^3 \cdot \text{s}}{\text{mol}}$$

This is also the area of the rectangle with vertices $(X, 1/-r_A)$ of $(0, 0)$, $(0, 16)$, $(0.6, 16)$, and $(0.6, 0)$ (see Figure E2-2.1).

For the plug-flow (tubular) reactor:

$$\begin{aligned} \frac{V}{F_{A0}} &= \int_0^{0.6} \frac{dX}{-r_A} = \text{area under the curve between } X = 0 \text{ and } X = 0.6 \\ &\quad (\text{see appropriate shaded area in Figure E2-2.1}) \\ &= 5.1 \frac{\text{dm}^3 \cdot \text{s}}{\text{mol}} \end{aligned}$$

For the same flow rate F_{A0} , the plug-flow reactor requires a smaller volume than the CSTR to achieve a conversion of 60%.

Generally, the isothermal tubular reactor volume is *smaller* than the CSTR for the same conversion




Figure E2-2.1

ol. The tubular
s/g mol) by F_{A0}
aphical integra-

-flow reactor
Figure 2-1 to
conversion of
same in both

2.4 Reactors in Series

Many times reactors are connected in series such that the exit stream of one reactor is the feedstream for another reactor. When this occurs it is often possible to speed the calculations by defining the conversion in terms of location at a point downstream rather than with respect to any one reactor. That is, the conversion X is the total moles of A that have reacted up to that point per mole of A fed to the first reactor. However, this definition can only be used provided that there are no side streams withdrawn and the feedstream enters only the first reactor in the series.

As an example, the relationships between conversion and molar flow rates for the reactor sequence shown in Figure 2-3 are given by the following equations:

$$F_{A1} = F_{A0} - F_{A0}X_1$$

$$F_{A2} = F_{A0} - F_{A0}X_2$$

$$F_{A3} = F_{A0} - F_{A0}X_3$$

0, 0), (0, 16),

$X = 0.6$
(2.1)




FIGURE 2-3

Figure 2-3

volume than